


# CYC Auto Start/Timer System

## SET UP:

1. Remove Start System from Cupboard. Check Lights/Sound and Battery UPS are plugged in and turned on. (If Light/Sound is not plugged in and turned on the system will still work but no lights or sound will be active.)



2. Plug 12v power supply into UPS and Start System, turn on On/Off switch at side of box.



Power Supply



On/Off Switch

3. Plug Blue Cat5 cable into Start System and Wall Plate marked for system. There is a wall plate in the Race Control Room and one in the Radio Room - either can be used. (If this is not plugged in the system will still work but no lights or sound will be active.)



Wall Plate  
Race Control Room



Wall Plate  
Radio Room

4. When the System is turned on the screen displays “To Begin Countdown Press Start/Lap” This button is on the top directly in front of screen clearly marked. The 3 red LED’s to the Left of screen correspond with the Start lights. The single red LED on the Right corresponds to the Sound Signal.

Lights      Sound

## AUTO START SEQUENCE:

5. Press the Start button: The start sequence will now start in exactly 1 minute. Then begins the 5 minute Start Sequence, activating all lights.  
At 4 minutes - 1st light will go out and a sound signal is given. At 1 minute - 2<sup>nd</sup> light will go out and a sound signal is given.  
At Start - 3rd light will go out and a sound signal is given.



Start Button

6. Stop Watch automatically begins.

“WARNING: DO NOT TURN OFF ONCE THE RACE BEGINS”

## RECORDING LAP/FINISH TIMES:

7. Press Start/Lap button and write down the times to correspond with the boat number. The system will display the last 3 boat times corresponding to each time the button is pressed.
8. Manual Sound Button. To notify boats of recall at start or boats as they finish. When you press this button the Red LED on the Right will come on and the sound signal will be given.

## EMERGENCY FLASHING SWITCH:

9. Only to be used to alert all boats to come ashore if a Weather/Personal Danger situation. Activates all 3 lights in a Flashing Mode.

## PACK UP:

10. Switch off Start System at side of box, 12v power supply, and Light/Sound at power point. Return Auto Start System to Cupboard.



Emergency Light  
Flasher

Please contact me if you have any questions. Gordon 0430 207 907